



# COMPACT series Inverter

## ELECTRICAL CONNECTIONS

**⚠ DANGER**

**RISK OF ELECTRIC SHOCK, EXPLOSION OR ELECTRIC ARC**

- Only suitably trained personnel, familiar with and capable of understanding the content of the manual and all relevant documentation, are authorised to work on and with this inverter. Furthermore, the personnel must have completed courses in safety and must be able to recognise and prevent the implied dangers. Installation, adjustment and maintenance must only be carried out by qualified personnel.
- Various product components, including the printed circuits, run at hazardous voltage levels.
- Only use electrically insulated and suitably calibrated measuring devices and equipment.
- Do not open, disassemble, repair or modify the product.
- Before handling the product, make sure you are wearing all the necessary personal protective equipment (PPE).
- Do not expose the equipment to liquids or chemicals.
- Before applying voltage to the inverter:
  - Make sure the running period has been completed and no parts of the system can become hazardous.
  - If the mains power supply terminals and the motor output terminals have been earthed and circuited, remove the earth and short circuits on these terminals.
  - Make sure all the equipment is properly earthed.
  - Make sure all protective elements, such as covers, hatches and grilles, are fitted and/or closed.
  - Check all wiring connections.

**FAILURE TO FOLLOW THESE INSTRUCTIONS WILL RESULT IN DEATH OR SERIOUS INJURY.**

**⚠ DANGER**

**RISK OF ELECTRIC SHOCK AND FIRE**

- Do not use the device with loads greater than those indicated in the technical data section.
- Do not exceed the temperature and humidity ranges indicated in the technical data section.
- Use the required safety interlocks (fuses and/or magnetothermal switches) of a suitable size between the power supply and the inverter.

**FAILURE TO FOLLOW THESE INSTRUCTIONS WILL RESULT IN DEATH OR SERIOUS INJURY.**

This device was designed to operate in non-hazardous environments, excluding applications that generate, or could potentially generate, hazardous atmospheres. Only install this device in areas and for applications which are reliably free from hazardous atmospheres.

**⚠ DANGER**

**RISK OF EXPLOSION**

- Only install and use this device in sites that are not at risk.
- Do not install or use this device in applications which are capable of generating hazardous atmospheres, such as applications that use flammable refrigerants.

**FAILURE TO FOLLOW THESE INSTRUCTIONS WILL RESULT IN DEATH OR SERIOUS INJURY.**


**⚠ WARNING**

**MALFUNCTIONING OF THE EQUIPMENT**

- Perform the wiring carefully, in compliance with electromagnetic compatibility requirements.
- Do not operate the product with unknown or incorrect settings or data.
- Carry out a full start-up test.
- Make sure the wiring is correct for the settings.
- Use shielded cables for all I/O signal and communication cables.
- Use double-shielded cables for motor wiring.
- Minimise the length of the connections as much as possible, to avoid winding the cables around electrically connected parts.
- The signal (communication and corresponding power supplies) and power cables for the device must be routed separately.
- Before applying the power supply, check all the wiring connections.


**FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN DEATH, SERIOUS INJURY, OR EQUIPMENT DAMAGE.**

## DIMENSIONS




## INSTALLING


Compact inverter installation anticipates the use of a corner bracket (not supplied).  
0.75 kW models




## 1.5 kW / 2.2 kW / 2.3 kW models



Install the Compact inverter observing the minimum distance of 40 mm (1.57 in.) on each side. Make sure there is a distance of at least 10 mm (0.39 in.) between the support base and the cooler.



## WIRING DIAGRAM



TERMINALS		TERMINALS	
L	PHASE - Power supply input	COM	Digital input common
N	NEUTRAL - Power supply input	NC	Relay output normally closed
PE	EARTH - Power supply input (*)	C	Relay output common
RS-485	RS-485 serial port for remote connection	NO	Relay output normally open
U	Motor control output	+12V	Cooler fans power supply
V	Motor control output	GND	
W	Motor control output	-	Analogue input for potentiometer with 5 Vdc power supply
PE	Motor earth connection (*)	Pot	
I1...I3	Digital inputs 1...3	+	

TECHNICAL DATA	
Ambient operating conditions:	-10...55 °C (14...131 °F) 10 ... 90% RH non-condensing
Transportation and storage conditions:	-20...60 °C (-4...140 °F) 10 ... 90% RH non-condensing
Altitude:	Maximum 1000 m (3280 ft)
Pollution category:	2
Protection degree:	IP00
Overvoltage category:	II
Power supply:	230 Vac ±10% 50/60 Hz
Input current (RMS):	0.75 kW: 5 A 1.5 kW: 10 A 2.2 kW: 15 A 2.3 kW: 15.5 A
Output current (RMS):	0.75 kW: 3.3 A 1.5 kW: 6.3 A 2.2 kW: 8.8 A 2.3 kW: 8.9 A
Cooling method:	0.75 kW models: Natural ventilation Other models: Forced ventilation

Other technical information	
<b>Input properties (SELV)</b>	
Digital inputs:	3 multifunctional configurable digital inputs
Analogue inputs:	1 configurable analogue input 0...10 V / 0...5 V
<b>Output properties</b>	
Digital outputs:	1 relay output 5 A at 250 Vac (configurable)
Motor output:	0...230 Vac, 3 ph at Vin = 230 Vac
Carrier frequency:	5...16 kHz
Nominal overload:	Maximum 150% for 60 seconds
Output frequency:	0...100 Hz
<b>Serial communication port properties (SELV)</b>	
RS-485 serial port:	1 opto-isolated RS-485 MODBUS RTU Slave serial port, reinforced for remote connection Maximum baud rate: 38400 bps - Maximum cable length: 1.5 m (4.9 ft)

**Compliance**  
CE in accordance with directives EN61800-3 and EN61800-5-1 in C2 category

## USER PARAMETERS TABLE

Par.	Description	MU	Range	Model default [kW]				PW
				0.75	1.5	2.2	2.3	
<b>Control Group S1-</b>								
S105	Automatic alarm reset delay time.	s	0.1 ... 60.0	5.0	5.0	5.0	5.0	U
S106	Enable/Disable the Safe Start function. 0 = Function disabled; 1 = Function enabled.	-	0 ... 1	0	0	0	0	U
<b>Speed Group S2-</b>								
S201	Nominal target speed. If S101 = 2, 4 or 5, the nominal speed is set.	rpm	S205 ... S204	1000	1000	1000	1000	U
S202	Acceleration ramp. Time required to reach the nominal speed from 0 rpm.	s	0.2 ... 200.0	3.0	3.0	3.0	3.0	U
S203	Deceleration ramp. Time required to reach 0 rpm from the nominal speed.	s	0.2 ... 200.0	5.0	5.0	5.0	5.0	U
S204	Maximum motor speed <sup>(1)</sup> .	rpm	S205 ... S204	1500	1500	1500	1500	U
S205	Minimum motor speed <sup>(1)</sup> .	rpm	S205 ... S204	300	300	300	300	U
S207	Multi-speed 1 <sup>(3)</sup> .	rpm	S205 ... S204	1100	1100	1100	1100	U
S208	Multi-speed 2 <sup>(3)</sup> .	rpm	S205 ... S204	1200	1200	1200	1200	U
S209	Multi-speed 3 <sup>(3)</sup> .	rpm	S205 ... S204	1300	1300	1300	1300	U
S210	Multi-speed 4 <sup>(3)</sup> .	rpm	S205 ... S204	1400	1400	1400	1400	U
S211	Motor potentiometer step. Selection of the number of steps between minimum speed and maximum speed.	-	1 ... 100	10	10	10	10	U
S212	Torque reference. Torque threshold for activating the opposite motor rotation direction.	Nm	0.0 ... S507	0.0	0.0	0.0	0.0	U
S213	Reverse number. Select the number of attempts permitted with the opposite motor rotation direction.	-	0 ... 20	0	0	0	0	U
S214	Reverse time. Time during which the motor rotates in the opposite direction.	s	1 ... 200	5	5	5	5	U
S215	Speed jump 1.	rpm	S205 ... S204	300	300	300	300	U
S216	Speed jump 2.	rpm	S205 ... S204	300	300	300	300	U
S217	Speed jump band. Interval size for target speeds to be jumped. 0 = disabled.	rpm	0 ... S205	0	0	0	0	U

**NOTE:** The User level, where no password is required, is considered as Level 0 (U)

<sup>(1)</sup> The minimum and maximum limits are calculated based on the number of pole pairs for the motor, between 5 and 100 Hz;  
<sup>(2)</sup> Looking at the motor with the shaft positioned to the front;  
<sup>(3)</sup> By combining two of the three inputs available, you can obtain 4 speed targets; See parameters S304...S306 in paragraph "8.1 Table of configuration parameters" on page 22 in the manual hardware with p/n 114E1XX14.00

## ALARMS

Code	Description	No. of red LED flashes	Cause	Alarm solution
UV	Undervoltage alarm	1	The voltage value of the device has dropped below the minimum value set via parameter S602	Reset alarm from governing input or automatically with the AUTORESET function when enabled
OV	Overvoltage alarm	2	The voltage value of the device has exceeded the maximum value set via parameter S603	
OC	Overcurrent alarm	3	The device has exceeded the maximum current value set via parameter S601	
OL	Overload alarm	4	When the amount of energy according to logic I <sup>2</sup> t exceeds the value set via parameters S511 and S512	
BT	Circuit board overtemperature alarm	5	The device has reached and exceeded the maximum permitted temperature set via parameter S604	The alarm resets automatically when the device temperature drops to 10 °C (50 °F) below the temperature threshold set via parameter S604
OT	Cooler overtemperature alarm	6	The motor has reached and exceeded the maximum permitted temperature set via parameter S605	The alarm resets automatically when the motor temperature drops to 10 °C (50 °F) below the temperature threshold set via parameter S605
AI	Analogue input alarm	7	Hardware malfunction, cannot read the analogue input	Contact the manufacturer (the board needs to be repaired)
EP	Eeprom data alarm	8	The data structure is not intact	The default values are restored automatically. The parameters changed previously need to be re-entered manually
TO	Communication timeout alarm	9	MODBUS communication interrupted	Check connection
US	User alarm	10	Alarm associated with an input	Remove the cause of the alarm
PS	Phase Lose alarm	12	<ul style="list-style-type: none"> <li>Motor not connected correctly</li> <li>Incorrect S534 sensitivity</li> </ul>	<ul style="list-style-type: none"> <li>Check the power supply wiring;</li> <li>Change parameter S534.</li> </ul>
MT	Motor thermal switch alarm	13	Alarm associated with an input (S304...S306 = 17)	Remove the cause of the alarm
MS	Motor stall alarm	14	<ul style="list-style-type: none"> <li>Motor does not rotate properly with vector algorithm;</li> <li>Incorrect S535 sensitivity</li> </ul>	<ul style="list-style-type: none"> <li>Make sure parameters S500...S527 are correct;</li> <li>Change parameter S535</li> </ul>

## Disclaimer

This document is the exclusive property of EVCO. It contains a general description and/or a description of the technical specifications for the services offered by the products listed herein. This document should not be used to determine the suitability or reliability of these products in relation to specific user applications. Each user or integration specialist should conduct their own complete and appropriate risk analysis, in addition to carrying out a product evaluation and test in relation to its specific application or use. Users can send us comments and suggestions on how to improve or correct this publication.

Neither EVCO nor any of its associates or subsidiaries shall be held responsible or liable for improper use of the information contained herein.

EVCO has a policy of continuous development. Therefore, EVCO reserves the right to make changes and improvements to any product described in this document without prior notice.

The technical data in this manual is subject to change without prior notice.

**Consider the environment**  
Please consider the environment before printing this document.

**Disposal**  
The device must be disposed of in accordance with local regulations regarding the collection of electrical and electronic appliances.