

\bigcirc ITALIANO IMPORTANTE

1.1 Importante

Leggere attentamente queste istruzioni prima dell'installazione e prima dell'uso e seguire tutte le avvertenze per l'installazione e per il collegamento elettrico; conservare queste istruzioni con il dispositivo per consultazioni future.

Il dispositivo deve essere smaltito secondo le normative locali in merito alla raccolta delle apparecchiature elettriche ed elettroniche

DIMENSIONI E INSTALLAZIONE

2.1 Dimensioni Si veda il disegno del paragrafo 2.1 della sezione in Inglese

Le dimensioni sono espresse in mm (in).

Il disegno sulla sinistra illustra la versione con interruttori: il disegno al centro illustra la versione senza interruttori.

2.2 Installazione

2

Con riferimento al disegno del paragrafo 2.2 della sezione in Inglese, il

dispositivo è composto da:

- 1 guscio frontale preassemblato con strumento, staffe di a) fissaggio dello strumento, poliestere e interruttori (se previsti)
- b) 1 guscio posteriore
- 2 tappi copriviti di assemblaggio dei gusci C)
- d) 2 linguette di assemblaggio dei gusci
- 8 faston femmina isolati (solo nella versione con interruttoe)
- f) 1 passacavo per tubo rigido Ø 20,0 mm (0,787 in)
- g 2 viti di assemblaggio dei gusci
- 2 guarnizioni per viti di assemblaggio dei gusci h
- i) 1 guarnizione per guscio posteriore
- 2 tasselli Ø 6,0 mm (0,236 in) da muro e relativi viti di fisj) saggio del guscio posteriore
- k) 2 guarnizioni per viti di fissaggio del guscio posteriore
- tracce per fori per viti di fissaggio del guscio posteriore I)
- tracce per foro per passacavo per tubo rigido. m)
- Per installare il dispositivo operare nel modo indicato:
- Effettuare due fori nelle tracce I).
- 2 Se si desidera che i cavi vengano infilati dall'alto o dal basso, effettuare un foro in una delle tracce m); se si desidera che i cavi vengano infilati da dietro, effettuare un foro sul retro del guscio b).
- Effettuare due fori Ø 6,0 mm (0,236 in) nella parete dove si intende installare il dispositivo utilizzando le tracce I) forate come guida
- Infilare i tasselli j) nei fori della parete.
- Se si desidera che i cavi vengano infilati dall'alto o dal bas-5 so, assemblare il passacavo fl in una delle tracce ml forata.
- 6 Infilare le quarnizioni k) nelle viti j) Se si desidera che i cavi vengano infilati da dietro, siliconare il retro del guscio b) lungo l'asola in rilievo e lungo i due seamenti verticali.
- 8 Fissare il guscio b) alla parete attraverso le viti j) e le guarnizioni k).
- 9 Appoggiare il guscio a) al guscio b) e infilare le linguette d). 10 Lasciare il guscio a) a sbalzo, per poter operare all'interno del dispositivo.
- 11 Infilare i cavi di collegamento nel guscio b)
- 12 Effettuare il collegamento elettrico dello strumento preassemblato e degli interruttori (se previsti; si veda il capitolo 3); per collegare gli interruttori utilizzare i faston e).
- 13 Applicare la guarnizione i) nel guscio b) posizionandone le estremità nella parte inferiore del guscio.
- 14 Applicare nuovamente il guscio a) al guscio b) e fissarlo attraverso le viti g) e le guarnizioni h).
- 15 Applicare i tappi c)

COLLEGAMENTO ELETTRICO 3

3.1 Esempio di collegamento elettrico

Si veda il disegno del paragrafo 3.1 della sezione in Inglese

- Nell'esempic
- la versione è con interruttori
- · l'alimentazione dello strumento preassemblato è 230 VCA
- · il controllo della luce è indipendente dallo stato dello strumento preassemblato.
- Si vedano anche le istruzioni dello strumento preassemblato. **CODICI DISPONIBILI**

4.1 Codici disponibili

ASOKB31000: frontecella preassemblato con EVKB31N7 (il buzzer di allarme e la porta seriale non sono supportati), staffe di fissaggio dello strumento, poliestere e interruttori.

ASOKB33000: frontecella preassemblato con EVKB33N7 (il buzzer di allarme e la porta seriale non sono supportati), staffe di fissaggio dello strumento, poliestere e interruttori

DATI TECNICI 5.1 Dati tecnici

Contenitore: autoestinguente grigio

Grado di protezione del frontale: IP 65.

Connessioni: morsettiere a vite (strumento preassemblato), faston da 6,3 mm (0,248 in, interruttori, se previsti).

Temperatura di impiego: da 0 a 55 °C (da 32 a 131 °F, 10 ... 90% di umidità relativa senza condensa).

Alimentazione: 230 VCA, 50/60 Hz, 3 VA (approssimativi).

Interruttori (se presenti): 2 interruttori bipolari da

Si vedano anche le istruzioni dello strumento preassemblato.



EVCO S.p.A.

Via Mezzaterra 6. 32036 Sedico Belluno ITALY Phone +39-0437-852468 • Fax +39-0437-83648

This document belongs to Evco; unless you are authorized by Evco, you can not publish this document. Evco does not take any responsibility about features, technical data and possible mistakes related in this document. Evco does not take any responsibility about damages coming by the non-observance of additional information. Evco reserves the right to make any change without prior notice and at any time without prejudice the basic safety and operating features.

30/10 Н

10 A res. @ 250 VCA.

Evco S.p.A. Code 104K203E07

EVK203/EVK213/EVK223/EVK233/EVK253 Digital thermostats for ventilated refrigerating units



press set			and if parameter i0 has v
• press	🖟 or 👿 in 15		Remedies:
press set	or do not operate 15 s.		check the reasons that
o quit the	e procedure:		the multipurpose input
press	and 🔽 4 s or do not operate 60 s.		switch off/on the powe
Switch o	ff/on the power supply of the instrument after the		Iook at parameters i1, i!
modifica	tion of the parameters.		Effects:
3.3 Rest	toring the default value of configuration parameters		• the regulators will be tu
make su	re no procedure is running	СОН	Overheated condenser a
Dress	and 💽 4 st the display will show "PA"		Remedies:
			check the condenser te
Pross Set	or The in 15 s to set "742"		 look at parameter C6
	D or do pot operate 15 s		Efforte:
set			Lifects.
• press	and V 4 s: the display will show dEF		• no effect
press set		CSd	Compressor locked alarm
• press) or 🕎 in 15 s to set " 149 "		Remedies:
press set	or do not operate 15 s: the display will show " dEF " flash-		check the condenser te
	ing 4 s, after which the instrument will quit the procedure		 cut off the power supp
switch o	ff/on the power supply of the instrument.		condenser
Make su	re the default value of the parameters is appropri-		Iook at parameter C7
ate, in p	articular if the probes are PTC probes.		Effects:
4 SIGI	NALS		• the compressor and the
4.1 Sigr	nals	When the	e cause that has provoked
LED	MEANING	ment rest	ores the normal operation,
20	LED compressor	alarm (co	de " iSd ") and the compress
CD	if it is lit, the compressor will be turned on	need you	switch off/on the power s
	if it flashes:	6 INT	FRNAL DIAGNOSTICS
	 the modification of the working setepint will be running 		
	• the modification of the working setpoint will be running	0.1 Inte	
	- a compressor protection will be running (parameters CO,	CODE	
		Pr1	Cabinet probe error
*	LED defrost		Kemedies:
	If it is lit, the defrost will be running		 look at parameter P0
	if it flashes:		check the integrity of the integrity
	 the defrost will be required but a compressor protection 		check the connection in
	will be running (parameters C0, C1 and C2)		 check the cabinet temp
	 the dripping will be running (parameter d7) 		Effects:
	• the heating of the freezing fluid will be running (param-		• the compressor activity
	eter dA)		C5
Ø.	LED evaporator fan	Pr2	Evaporator probe error
ge	if it is lit, the evaporator fan will be turned on		Remedies:
	if it flashes, the after dripping evaporator fan delay will be		• the same you saw in th
	running (parameter E3)		evaporator probe
•	LED alarm		Effects:
Ш	if it is lit an alarm will be running		if parameter P3 bas val
°r	LED Colring dograp		- II paraineter i 5 has vai
C	LED Celsius deglee		you will have set with p
	If it is lit, the unit of measure of the temperatures will be		 If parameter P3 has value
	Celsius degree (parameter P2)		the instrument will wor
۴F	LED Fahrenheit degree		• if parameter F0 has valu
	if it is lit, the unit of measure of the temperatures will be		as if the parameter had
	Fahrenheit degree (parameter P2)	Pr3	Condenser probe error (o
CODE	MEANING		Remedies:
Loc	the keyboard and/or the working setpoint are locked (pa-		• the same you saw in th
	rameter r3); also look at paragraph 2.7		condenser probe
	the quantity to show is not available (for example because		Effects:
	the probe is not enabled)		• the overheated conder
i ALA	ARMS		compressor locked alar
1 Ala	ims		vated
CODE	MEANING	When the	o cause that has provoked
AL		mont mot	ores the normal operation
AL		ment lest	ores the normal operation.
	kemedies:	/ TEC	MINICAL DATA
	 cneck the temperature joined to the alarm 	7.1 Tec	nnical data
	 look at parameters A0, A1 and A2 	Box: self-	extinguishing grey.
	Effects:	Frontal	protection: IP 65.
	• no effect	Connect	ions (use copper condu
AH	Upper temperature alarm	(power su	upply, inputs and outputs),
	Remedies:	request),	4 poles connector (to the
	 check the temperature joined to the alarm 	available i	in EVK223, EVK233 and EV
	Iook at parameters A3, A4 and A5	and 115	VAC); extractable terminal
	Effects:	outputs) t	by request.
	• no effect	Working	temperature: from 0 to
id	Door switch input alarm /onlv FVK213_F\/K223 and F\/K233	relative bu	umidity without condensate
	and if parameter i0 has value 2 or 31	Power	supply EVK203 and
	Remedies:	3 \/A /app	proximate): 115 \/AC or 12
	check the reasons that have provoked the activation of		
	the input	Power -	
	 look at parameters i0 and i1 	12 24 V/44	C/DC by request
		12-24 VA	Cruc by request.
	Ellects:	Power s	upply EVKZZ3 and EV
	the effect you have set with parameter i0	(approxim	nate); 115 VAC by request.
iA	Multipurpose input alarm (only EVK213, EVK223 and EVK233	Insulatio	on class: 2.
	and if parameter i0 has value 0)	Alarm b	uzzer: by request.
	Remedies:	Measure	e inputs EVK203, EVK2
	• check the reasons that have provoked the activation of	(cabinet p	probe and evaporator prob
	the input	Measure	inputs EVK253: 3 (cab
	Iook at parameters i1 and i5	condense	r probe) for PTC/NTC prob
	Effects	Digital	nouts (only FV/K212 E
	if parameter i5 has value 3, there will be po offect	tipurpose	/door switch) for NO/NC c
	if parameter i5 has value 4, the compressors will be to the	Working -	range from E0.0 to 150
		from 40.4	1011-50.0 to 150
		1 10111-40.0	u iu iu∋.u ⊂ (-40 to 220 °
		D • • •	

To modify a parameter

iSd Instrument locked alarm (only EVK213, EVK223 and EVK233 and if parameter i0 has value 0)

have provoked the activation of

ver supply of the instrument i5, i7, i8 and i9

urned off alarm (only EVK253)

emperature

(only EVK253)

emperature bly of the instrument and clean the

e evaporator fan will be turned off I the alarm disappears, the instru-, except for the instrument locked sor locked alarm (code "**CSd**") that upply of the instrument.

he probe instrument-probe perature

will depend on parameters C4 and

ne previous case but related to the

alue 1, the defrost will last the time parameter d3

lue 1 and parameter d8 has value 2, ork as if parameter d8 had value 0 Ilue 3 or 4. the instrument will work

d value 2 (only EVK253)

ne previous case but related to the

nser alarm (code "**COH**") and the rm (code "**CSd**") will never be acti-

the alarm disappears, the instru-

uctors only]: screw terminal blocks , 6 poles connector (serial port; by e remote indicator; by request, not VK253 with power supply 230 VAC I blocks (power supply, inputs and

55 °C (32 to 131 °F, 10 ... 90% of

EVK253: 230 VAC, 50/60 Hz, 2-24 VAC/DC or 12 VAC/DC by re-

DC, 50/60 Hz, 3 VA (approximate);

K233: 230 VAC, 50/60 Hz, 3 VA

213, EVK223 and EVK233: 2 be) for PTC/NTC probes. binet probe, evaporator probe and

es. EVK223 and EVK233): 1 (mul-

:ontact (free of voltage, 5 V 1 mA).).0 °C (-50 to 300 °F) for PTC probe, 'F) for NTC probe.

Digital outputs: 3 relays:

- compressor relay: 16 res. A @ 250 VAC, 5 FLA, 30 LRA (NO contact) in EVK203, EVK213 and EVK253 (this last with power supply 12 VAC/DC and 12-24 VAC/DC); 30 res. A @ 250 VAC, 12 FLA, 72 LRA (NO contact) in EVK233; 8 res. A @ 250 VAC, 2 FLA, 12 LRA otherwise
- defrost relay: 8 res. A @ 250 VAC, 2 FLA, 12 LRA (change-over contact)
- evaporator fan relay: 8 res. A @ 250 VAC, 2 FLA, 12 LRA (NO contact) in EVK203, EVK213 and EVK253 (this last with power supply 12 VAC/DC and 12-24 VAC/DC); 5 res. A @ 250 VAC otherwise.

The maximum current allowed on the loads is 10 A.

Serial port: port for the communication with the supervision system (through a serial interface, via TTL, with MODBUS communication protocol) or with the programming key; by request.

Further communication ports: port for the communication with the remote indicator; by request, not available in EVK223, EVK233 and EVK253 with power supply 230 VAC and 115 VAC.

8 WORKING SETPOINTS AND CONFIGURATION PARAMETERS						24) min	1	5	upper temperature alarm delay since the end of the after dripping evaporator fan delay (only if A3 = 0)	ator fan delay (only if A3 = 0) (17) make sure the time you have set with parameter i7 is shorter than the one you have set with parameter i9.	
8.1 Worki	ng setpo	ints			40	24) min	1	c	(12)	The instrument must be dispered according to the local legislation about the collection for electrical and ele	
r1	r2	°C/°F (1)	0.0	working setpoint		24	, , , , , , , , , , , , , , , , , , , ,	1.		and EVK233] (13)	The instalment must be disposed according to the local registration about the collection for electrical and ele	
8.2 Config	juration	paramete	rs	1 · 5 · 4· · ·	PARAM. I	MIN. MA	X. U.M.	. D	EF.	EVAPORATOR FAN		
PARAM. MIN	MAX.	U.M.	DEF.	WORKING SETPOINTS	F0 () 4		1		evaporator fan activity during the normal operation		
SP r1	r2	°C/°F (1)	0.0	working setpoint						0 = turned off		
CA1 -25 () 25.0	°C/°F (1)	0.0	cabinet probe offset						2 = according to the compressor		
CA2 -25.0	25.0	°C/°F (1)	0.0	evaporator probe offset						3 = according to F1 (14)		
CA3 -25.0) 25.0	°C/°F (1)	0.0	condenser probe offset (only EVK253)						4 = turned off if the compressor is turned off, according to F1 if the compressor is turned on (14)		
P0 0	1		1	kind of probe	F1 -	99.0 99.	0 °C/°	F(1) -1	.0	evaporator temperature above which the evaporator fan is turned off (only if $F0 = 3 \text{ or } 4$) (4)		
				0 = PTC	F2 (2		0		evaporator fan activity during the defrost and the dripping		
P1 0	1		1	I = NIC								
	'			1 = YES						$2 = \operatorname{according} to F0$		
P2 0	1		0	unit of measure temperature (2)	F3 () 15	min	2		duration of the after dripping evaporator fan delay		
				0 = °C	PARAM. I	MIN. MA	X. U.M.	. D	EF.	DIGITAL INPUTS (only EVK213, EVK223 and EVK233)		
				1 = °F	iO () 3		2		kind of digital input		
P3 0	2		1	evaporator probe function						0 = <u>MULTIPURPOSE INPUT</u> - in this case look at parameters 11, 15, 17, 18 and 19		
				1 = defrost probe and thermostat probe for the evaporator fan						2 = DOOR SWITCH INPUT - in this case look at parameters i1 i2 and i3: the activation of the input will		
				2 = thermostat probe for the evaporator fan						turn off the evaporator fan (at most the time i3 or as long as the input will be deactivated)		
P4 0	1		1	enabling the condenser probe (only EVK253)						3 = DOOR SWITCH INPUT - in this case look at parameters i1, i2 and i3; the activation of the input will		
				1 = YES						turn off the compressor and the evaporator fan (at most the time i3 or as long as the input will be		
P5 0	4		0	quantity to show during the normal operation						deactivated) (15)		
				0 = cabinet temperature	i1 (2		0		kind of contact digital input		
				2 = evaporator temperature						1 = NC (the input will be active if you open the contact)		
				3 = "cabinet temperature - evaporator temperature"						2 = input not enabled		
				4 = condenser temperature (only EVK253, not visible otherwise)	i2 -	1 12) min	30	0	delay to signal the door switch input alarm		
PARAM. MIN	MAX.	U.M.	DEF.	MAIN REGULATOR						-1 = no signal		
r0 0.1	15.0	°C/°F (1)	2.0	working setpoint differential	i3 -	1 12) min	1	5	maximum duration of the effect provoked by the activation of the door switch input		
ri -99.0	1 r2	C/F (1)	-50.0		iE /					- I = une elect Will last as long as the input Will be deactivated		
r3 0	1		0.0	locking the working setpoint modification (with the procedure related in paragraph 3.1)	i) Ci			3		0 = no effect		
Ŭ	ľ		T.	1 = YES						1 = <u>SYNCHRONIZING THE DEFROSTS</u> - spent the time d5 the defrost will be activated (16)		
r4 0.0	99.0	°C/°F (1)	0.0	temperature increase during function Energy Saving (only EVK213, EVK223 and EVK233); also look at i5						2 = <u>ACTIVATING THE ENERGY SAVING</u> - function Energy Saving will be activated (as long as the input		
PARAM. MIN	MAX.	U.M.	DEF.	COMPRESSOR PROTECTIONS						will be deactivated); also look at r4 (16)		
C0 0	240	min	0	compressor delay since you turn on the instrument					-	3 = ACTIVATING THE EXTERNAL ALARM - spent the time i7 the display will show the code "IA" flashing		
C1 0	240	min	5	minimum time between two activations in succession of the compressor; also compressor delay since						and the buzzer will be activated (as long as the input will be deactivated)		
C2 0	240	min	3	minimum time the compressor remains turned off						flashing and the buzzer will be activated (as long as the input will be deactivated): also look at i7. i8		
C3 0	240	s	0	minimum time the compressor remains turned on						and i9		
C4 0	240	min	10	time the compressor remains turned off during the cabinet probe error; also look at C5						5 = TURNING OFF THE INSTRUMENT - the instrument will be turned off via software (as long as the		
C5 0	240	min	10	time the compressor remains turned on during the cabinet probe error; also look at C4						input will be deactivated); also look at C0, d4 and A6		
C6 0.0	199.0	°C/°F (1)	80.0	condenser temperature above which the overheated condenser alarm is activated (only EVK253) (4)						6 = <u>ACTIVATION COOLING (only EVK213 and EVK223</u>) - the compressor will be turned on (as long as		
C7 0.0	199.0	-C/-F (1)	90.0	compressor locked alarm delay (only EVK253)	i7 () 12) min	0		the input will be deactivated); in this case parameters C4 and C5 are not meaningful (16) if i5 = 3, delay to signal the multipurpose input alarm		
PARAM MIN	MAX	UM	DEE	DEFROST			, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	0		if $i5 = 4$ compressor delay since the deactivation of the multipurpose input (17)		
d0 0	99	h	8	defrost interval; also look at d8 (6)	i8 () 15		0		number of multipurpose input alarms such as to provoke the instrument locked alarm (only if $i5 = 4$)		
				0 = the defrost at intervals will never be activated						0 = alarm not enabled		
d1 0	1		0	kind of defrost	i9	1 99	min	24	40	time without multipurpose input alarms in order that the alarm counter is cleared (only if i5 = 4)		
				0 = electric defrost	PARAM.	MIN. MA	X. U.M.	. D	EF.	SERIAL NETWORK (MODBUS)		
d2 -99 () 99.0	°C/°E (1)	2.0	defrost cutoff temperature (only if P3 = 1)) 3		2	47	baud rate		
d3 0	99	min	30	defrost duration if P3 = 0 or 2; defrost maximum duration if P3 = 1		· -		-		0 = 2,400 baud		
				0 = the defrost will never be activated						1 = 4,800 baud		
d4 0	1		0	defrost when you turn on the instrument						2 = 9,600 baud		
			0	1 = YES	1.0			2		3 = 19,200 baud		
d5 0	1		1	derives delay when you turn on the instrument (only if $d4 = 1$), also look at 15				2		parity 0 = pope		
	ľ		ſ	0 = cabinet temperature						1 = odd		
				1 = if to the defrost activation the cabinet temperature is below "working setpoint + r0", at most "work-						2 = even		
				ing setpoint + r0"; if to the defrost activation the cabinet temperature is above "working setpoint +	PARAM. I	MIN. MA	X. U.M	. D	EF.	RESERVED		
			-	r0", at most the cabinet temperature to the defrost activation (7)	E9 (0 1		1		reserved		
d/ 0	15	min	2	dripping duration	(1) t	ne unit of	measure o	lepends	on pai	the regulators appropriately after the medification of the economic P3		
00	L _		0	0 = the defrost will be activated when the instrument will have remained turned on the time d0	(2)	f paramete	C1 has	alue 0 1	the del	lav since the end of the cabinet probe error will however be 2 min		
				1 = the defrost will be activated when the compressor will have remained turned on the time do	(4) t	he differen	tial of the	parame	ter is 2	.0°C/4°F		
				2 = the defrost will be activated when the evaporator temperature will have remained below the tem-	(5) i	f (when yo	u turn on	the instr	ument	;) the condenser temperature is above the one you have set with parameter C7, parameter C8 will have		
			-	perature d9 the time d0 (8)	1	no effect						
d9 -99.0	99.0	°C/°F (1)	0.0	evaporator temperature above which the count of the defrost interval is suspended (only if $d8 = 2$)	(6) t	he instrum	ent stores	the cour	nt of th	e defrost interval every 30 min; the modification of parameter d0 has effect since the end of the previous		
dA 0	99	min	0	minimum time the compressor must be remained turned on (to the defrost activation) in order that the defrost can be activated (only if $d_1 = 1$) (9)	(7)	petrost inte	val or sin	ce the a	ctivatio	on or a derrost by hand		
PARAM MIN	MAX	U.M	DEF	TEMPERATURE ALARMS	1 1	he one the	t has lock	ed the c	ai oper displav	(or if a temperature alarm arises)		
A0 0	2		0	temperature joined to the lower temperature alarm	(8) i	f paramete	· P3 has v	alue 0 o	r 2, the	e instrument will work as if parameter d8 had value 0		
				0 = cabinet temperature	(9) i	f (to the de	frost activ	ation) th	ne dura	ation of the activation of the compressor is shorter than the time you have set with parameter dA, the		
				1 = evaporator temperature (10)		ompressor	will furth	er remai	n turne	ed on the fraction of time required to complete it		
41 00 0		90.05 (1)	10.0	2 = condenser temperature (only EVK253, not visible otherwise) (11)	(10) i	f paramete	P3 has v	alue 0, t	he inst	trument will work as if parameter A0 had value 0		
A1 -99.0	v 99.0 2	F(I) 	1	kind of lower temperature alarm	(11) 1	i paramete turina the	r# nas v defrost ++	alue 0, t ne drippi	ne inst na anc	unieni, will work as it parameter had value U d the evaporator fan delay the temperature alarms are not enabled, on condition that they have arisen		
, vz 0	2		[0 = alarm not enabled	(12) (annig trie after the ac	ivation ด	rc unppl f the def	rost	a die evoporator fan delay die temperature alarms are not enabled, on condition mat they have ansen		
				1 = relative to the working setpoint (or "working setpoint - A1"; consider A1 without sign)	(13)	during the	activation	of the de	oor swi	itch input the upper temperature alarm is not enabled, on condition that it has arisen after the activation		
				2 = absolute (or A1)		of the inpu						
A3 0	3 0 1 0 temperature joined to the upper temperature alarm (only EVK253, not visible = 0 otherwise)				(14) if parameter P3 has value 0, the instrument will work as if parameter F0 had value 2							
				0 = cabinet temperature	(15) 1	he compre	ssor is tui	ned off	spent	10 s since the activation of the input; if the input is activated during the defrost or the after dripping		
44 000		0C/0F /11	10.0	1 = condenser temperature (11)	(12)	evaporator	tan delay,	the acti	vation	will provoke no effect on the compressor		
A5 0	, 77.U 2		1	kind of upper temperature alarm	(10) 1	ne ellect is	not signa	med				
-	-		T.	0 = alarm not enabled								
				1 = relative to the working setpoint (or "working setpoint + A4"; consider A4 without sign)	_				EVCO	O S.D.A.	This document belongs to Evico, unless you are authorized b	
				2 = absolute (or A4)					Via M	ezzaterra 6, 32036 Sedico Belluno ITALY	Evco does not take any responsibility about features, technical data and possible mistakes related in this d	
A6 0	240	min	120	upper temperature alarm delay since you turn on the instrument (only if A3 = 0)	ы Н				Phone	e +39-0437-852468 • Fax +39-0437-83648	Evco does not take any responsibility about damages coming by the non-observance	
~ 0	∠4U	1000	115	Itemperature alarmituelay	⊨ Ever	y Cont	rol G	roup	info@)evco.it • www.evco.it	Evco reserves the right to make any change without prior notice and at any time without prejudice the basic	

nt must be disposed according to the local legislation about the collection for electrical and electronic equipment.

This document belongs to Evco; unless you are authorized by Evco, you can not publish it. not take any responsibility about features, technical data and possible mistakes related in this document or coming by its use. Evco does not take any responsibility about damages coming by the non-observance of the additional information. Evco reserves the right to make any change without prior notice and at any time without prejudice the basic safety and operating features.